

RadioMate® SwitchMatell™ Headset Interface

General Information

The **SwitchMatell™** headset interface allows the user to wear a headset and converse on a landline telephone as well as transmit on a two-way radio.

The headset interface is normally used at a dispatch point where the user receives telephone calls and dispatches service personnel or first responders by two-way radio.

The **SwitchMatell™** is powered by a wall plug-in transformer. The supplied metal mounting bracket and screws allow the unit to be conveniently placed under the writing surface. The unit may also be set on top of the desk top.

Please review the "Special Ordering Options", "Installing the **SwitchMatell™**" and "Using the **SwitchMatell™**" prior to set-up. Any additional questions can be directed to RadioMate® Sales and Customer Service staff by phone, email or website contact form.

(800) 346-6442

sales@radiomate.com

SwitchMate II™

Special Ordering Options

Each of RadioMate®'s SwitchMatell™ units is custom made. Because of this, we can accommodate many of our customer's different needs. Please review the following options that may be appropriate for your planned use of the equipment. Please indicate to us when you are ordering the options that are of interest to you. Options may or may not affect the price of the unit. It is our goal to supply you with a SwitchMatell™ specifically designed to fit your individual needs.

- **Dual Receiving:** Does the dispatcher need to listen to the telephone while transmitting on the radio? Or hear the radio traffic while conversing on the telephone? Please request "simultaneous receive" when ordering.
- **Recorder Output:** Will a recorder be used with the SwitchMatell™, and, if so, which side is to be recorded (telephone or radio or both)? Standard is that all audio that passes through the headset mic will be recorded. A SwitchMatell™ with recorder feature is a special order part.
- **Speaker Return:** Does the radio's speaker need to become live when the headset interface is unplugged from SwitchMatell™? This feature is included on all SwitchMatell™ boxes.
- **Contact Closure:** Do you have an external speaker? Please tell us when ordering.
- **Desk Microphone:** Do you want to use a desk microphone also? Please advise us when placing order. You may experience two live mics without possible modification.
- **Vehicle Installation:** Will this SwitchMatell™ be used in a vehicle? Please advise us how you plan to power the SwitchMatell™. We recommend installation of a line filter to suppress possible noise.

(800) 346-6442

sales@radiomate.com